

# 6250 AMP ULTRASAFE LITHIUM JUMP STARTER

# JUMP STARTER

The GB500+ is a 6250-amp portable lithium jump starter for gasoline and diesel engines up to 45-liters, including semi-trucks (up to class 8), motorhomes, coaches, buses, mining, agricultural, construction, and vocational equipment - 6, 8, 12, and 16 cylinder - and more.



**MASSIVE POWER**

RATED 6250A UP TO 45.0L+ JUMP START 12V/24V

**AUTO POWER CONSERVATION**  
START VEHICLE WITHIN 60 SECONDS

**SPARK PROOF**  
REVERSE POLARITY PROTECTION

**USB & 12V POWER**  
CHARGE & RECHARGE

**RAPID CHARGER**

**ULTRA BRIGHT**  
HIGH LUMENS FLASHLIGHT

**UNRIVALED PORTABILITY**

**INTEGRATED VOLTMETER**  
UNDERSTAND THE PROBLEM

**PORTABLE POWER**  
POWER 12V DEVICES

**Part Number: 815223**

## TECHNICAL SPECIFICATION




Starting Current	: 6250 Amps (Peak)
Voltage	: 12V & 24V
Battery Types	: 12V & 24V Lead-Acid Battery Systems
Internal Battery	: 266 Watt-Hour Lithium-Ion
Operating Temperature	: -22°F to 122°F (-30°C to +50°C)
Charging Temperature	: 32°F to 104°F (0°C to +40°C)
Storage Temperature	: -20°C to +50°C
USB (Output)	: Dual 5V, 2.1 Amps
Cooling	: Natural Convection
Dimensions (LxWxH)	: 12.3 x 8.2 x 6.3 in
Weight	: 19.25 lbs
12V XGC (Input)	: 14V @ 5 Amp
12V XGC (Output)	: 12.8V @ 15 Amp
Gas Engine Rating	: Up to 45.0 L, Safe On All Engine Sizes
Diesel Engine Rating	: Up to 45.0 L, Safe On All Engine Sizes
LED Worklight	: 2,200-Lumens

### What's in The Box

- GB500+ Lithium Battery Jump Starter
- Boost Max 24-Inch 2/0 AWG Connectors
- 56-Watt XGC Power Adapter
- 12-Volt Female Plug
- 12-Volt Male Plug
- 12-Volt 2-Foot XGC Cable
- Protective Carrying Case
- User Guide & Warranty Information



## FEATURES :

<p><b>POWER LED.</b></p>  <p>Illuminates white when unit is ON. Illuminates after 60-second timeout countdown. Remove clamps or power unit OFF/ON to reset.</p>	<p><b>CHARGE LEDS.</b></p>  <p>Indicates the charge level of the internal battery.</p>	<p><b>BOOST LED.</b></p>  <p>Illuminates white when boost is active. The LED flashes white when manual override feature is active.</p>
---	---	---

## MEASUREMENTS.

